



1+1 Console 8/16 ports combo VGA KVM Switch

UKS8108-ROT & UKS8116-ROT

User Manual

V3.0



Contents

1. Introduction	4
1.1 Main Features.....	4
1.2 Package Contents	5
1.3 Product Line	5
1.4 Front Panels	7
1.5 Port LED Indications	7
1.6 7-seg BANK LED	7
1.7 Buttons	8
1.8 Back Panels	8
2. Hardware Installation	9
2.1 Desktop or Rack Mount	9
2.2 Computer/Server Installation	11
2.2.1 CAT5 KVM on Host Side	11
2.2.2 3-in-1 VGA Cable Installation	12
2.3 Console Installation	13
2.3.1 Local Console	13
2.4 Optional Remote Console Installation	13
2.4.1 IP Module.....	13
2.4.2 CAT5 Transmitter Module	14
2.4.3 CAT5 KVM Receiver (R-Box)	14
2.5 Power Up Sequence	15
2.6 Daisy Chain Connection	16
3. Usage	18
3.1 Hotkey Commands and OSD Operations	18
3.2 DDC function.....	18
3.3 Hot Plug	18
3.4 Firmware Upgrade	19
4. Technical Specifications	20
5. Cable Connectors	21
5.1 3-in-1 VGA Cable	21
5.2 PS/2 keyboard to USB Changer.....	21
5.3 Daisy Chain Cable	21
5.4 CAT5/5E/6 Straight Through UTP/STP Cable	22
5.5 DC2.5M to DB9F Cable	22
6. Troubleshooting	23
7. Glossary	25
8. Certifications	26

Figures

Figure 1.	Front Panels of the Product Line	6
Figure 2.	Back Panels of the Product line	6
Figure 3.	Footpads Installation	9
Figure 4.	Rack Mount Installation -1	9
Figure 5.	Rack Mount Installation -2	10
Figure 6.	Computer/Server Installation	11
Figure 7.	3-in-1 VGA cable	12
Figure 8.	3-in-1 VGA Cable and PS/2 to USB Changer	12
Figure 9.	Local Console Installation	13
Figure 10.	IP-Module	14
Figure 11.	Daisy Chain Connection	16
Figure 12.	Daisy Chain through Computer Port.....	17
Figure 13.	3-in-1 VGA Cable Connectors	21
Figure 14.	PS/2 keyboard to USB Changer.....	21
Figure 15.	Daisy Chain Cable	21
Figure 16.	CAT5/5E/6 Straight Through Cable Connector (8P8C).....	22
Figure 17.	DC2.5M to DB9F Cable	22

1. Introduction

The 1+1 Console 8/16-port KVM switch can control attaching servers and computers from local or remote console. This KVM switch is loaded with features such as **one local console port, plus one optional CAT5-based remote console port or one optional IP-based remote console Port**, Daisy Chain, On Screen Display (OSD) Menu, Password security, Hot key Control, Push Button and Auto Scan Control. It has complete keyboard and mouse emulation for simultaneous computer boot-up processes.

With the CAT5-based remote console port you can remotely control servers and computers 1000 feet away. In other words, you can locate your monitor, keyboard and mouse up to 1000 feet away from the KVM switch. The built-in CAT5 transmitter synthesizes VGA monitor and keyboard/mouse signals, and transmit the signals to the remote CAT5 receiver over the popular LAN CAT5 cable.

With the IP-based remote console port you can control one or many computers locally at the server site or remotely via the Internet using a standard browser. You can securely gain BIOS level access to systems for maintenance, support, or failure recovery over the Internet. Communication is secure via SSL encryption.

The 1+1 console is designed as one control two viewers. Both local console and remote console can access and view the same computer port, but only one console control at a time. These two consoles are operating on first come first served basis, the non-controlling console will mirror the screen from the controlling console. If the controlling console does not have keyboard or mouse activity for 2 seconds, the other console may take over the control right.

1.1 Main Features

- 1+1 Console 8/16-port KVM switch
- Support full CAT5 interface on all computer ports for reducing KVM cable bulk
- Support one local console plus one optional remote console (CAT5 or IP)
- Locate CAT5 console up to 1000 feet (300 meters) away from KVM switch with superior **auto-adjust** RGB signals capability
- Support Microsoft Windows, Netware, Unix, and Linux
- Support iMAC, Power MAC and Sun Micro Systems with USB port
- No Software Required – easy computer selection via On Screen Display (OSD) Menu, Push Buttons, Hotkeys
- Provide various Hotkey (Scroll-Lock/ Caps-Lock/ Num-Lock/ Alt/ Ctrl/ Win) for switching

computer port and other control functions, so Hotkey function can be used in various types of keyboards, and to avoid Hotkey duplicate problem

- Support two levels of password security protections
- Provide ACL (Access Control List) security function, store up to 8 independent ACLs of controllable computer lists
- Hot Plug --- add or remove connected computers without powering off the KVM switch or computers
- Plug-n-Play monitor support
- Keyboard status restored when switching computers
- Support Daisy Chain function with both Bus (8-layer) and Tree (2-layer) topologies

1.2 Package Contents

- 1x KVM Switch Unit
- 1x CD-ROM (User manual, QSG)
- 1x AC to DC Power Adapter
- 1x Rack Mount Kit
- 1x Footpads set
- 1x DC2.5M to DB9F Cable

1.3 Product Line

Models

UKS8108-ROT	1+1 console 8-port, combo VGA, USB local console
UKS8116-ROT	1+1 console 16-port, combo VGA, USB local console

Optional Modules

UKS8500-C5	CAT5-T module
UKS8500-IP	KVM over IP module




Figure 1. Front Panels of the Product Line

UKS8108-ROT (1+1 Console, 8 ports combo VGA KVM switch with USB local console)



UKS8116-ROT (1+1 Console, 16 ports combo VGA KVM switch with USB local console)





Figure 2. Back Panels of the Product line

1.4 Front Panels



1.5 Port LED Indications

There are two LED's for each port:

- **ONLINE LED:** The **Red** LED on indicating a Computer is connecting to the port.
Notice: The PC99 Computer always power on the USB or PS/2 ports and turn on Red LED even if the Computer is not power on.
- **SELECT LED:** The **Green** LED on indicating the port has been selecting. The Green LED will be flashing if there is no Computer connected to the port.

1.6 7-seg BANK LED

The 7-segment BANK LED indicates the selected bank. Maximum 8 banks can be daisy chained. In the daisy chain configuration, there are two methods to select the bank (KVM unit) you want to operate: Hotkey and OSD.

1.7 Buttons and Operations

There are 11 push buttons on the front panel. The operations described in below.

(1) The “BANK” is the Bank Select Button.

You can select to the required bank number by press the “BANK” button.

The current accessed bank will be displayed at the 7-Segment LED.

The bank select were from 1 to 8 and go back to 1 cycling. It will increase the bank number from the current selected bank to the next bank if you pressed the “BANK” button once.

(2) The “1”, “2”, “3”, “4”, “5”, “6”, “7”, “8”, “9”, “0” are the port number select buttons


You can select to the required port number by

- Press the 2 digit port number to switch the port directly. For example if you are in port 1 now, press “0” then “6” will switch to the port 6 immediately.
- Press the port number and wait for 2 seconds to switch the port. At this case, you can only press single digit to select to the destination if the port number is between port 1 to port 9.

(3) If you pressed the invalid operation, the system will stay at the previous selected port.

(4) **RESET**: Press the “5” and “0” button simultaneously will restart the firmware of the KVM switch.

1.8 Back Panels



2. Hardware Installation

Before installation, please make sure all of peripherals and computers have been turned off.

2.1 Desktop or Rack Mount

The KVM switch unit can be placed on desktop or rack mounted.

Desktop

Stick the self-adhesive footpads that come with the package to the unit's bottom panel at the four corners. To install footpads, please turn upside down; and refer to the following instructions properly for installing the footpads.




Figure 3. Footpads Installation

Rack Mounting

The KVM switch unit can be mounted on 19"/1U rack:

1. Screw the mounting brackets into the sides of the unit at the front, as shown in the diagram below. Take note of the length of your cables so that your computers, KVM Switch, keyboard, mouse and monitor are distanced properly.




Figure 4. Rack Mount Installation -1

- Slide the unit into the rack and secure it to the rack.




Figure 5. Rack Mount Installation -2

2.2 Computer/Server Installation

2.2.1 CAT5 KVM on Host Side

Please refer to the “CAT5 Extender User Manual” for details. The figure below depicts the computer/server installation.




Figure 6. Computer/Server Installation

2.2.2 3-in-1 VGA Cable Installation

Each computer port connector is HDDB15 type. The 3-in-1 VGA cable has a HDDB15 male connector at one end. Plug it into computer port on the rear of KVM switch. The other end of input cable has three connectors: a HDDB15 male type for computer video, a purple mini din 6-pin PS/2 connector for keyboard and a green mini din 6-pin PS/2 connector for mouse. Plug these three connectors into the respective ports of computer. Repeat the same procedure for all other computers.

(a) PS/2 computer --- Plug in PS/2 mouse connector to computer mouse port, the PS/2 keyboard connector to computer keyboard port. Do not hot plug PS/2 port. If you must do that make sure PS/2 mouse first then the PS/2 keyboard.



Figure 7. 3-in-1 VGA cable

(b) USB computer --- connect PS/2-USB changer to PS/2 keyboard connector, then plug the changer into available USB port. This single USB port can communicate both keyboard and mouse signals. It works as a standard HID (Human Interface Device), no extra driver needed.



Figure 8. 3-in-1 VGA Cable and PS/2 to USB Changer

Note:

It is recommended to power off all the computers and server before the installation. If we can not turn off the computer, for PS/2 computer, please plug in T-dongle connectors in the following order: firstly PS/2 mouse connector, secondly PS/2 keyboard connector, thirdly the VGA connector to the computer.

2.3 Console Installation

2.3.1 Local Console

Connect the monitor to the HDB15 female port on the back of the KVM unit labeled with the monitor symbol at the Local Console connector.

There may be USB local console or PS/2 local console. For USB local console, connect the USB keyboard to either one of USB local port and USB mouse to the other USB port. These USB ports are special designed for keyboard and mouse, and can not work with USB hub or other USB devices. For PS/2 local console, connect keyboard to purple PS/2 port and mouse to green PS/2 mouse port. There is a Daisy chain port under VGA ports.




Figure 9. Local Console Installation

2.4 Optional Remote Console Installation

2.4.1 IP Module

Please refer to “IP KVM Module User Manual” for details.

IP Remote Console

Installation: Power off the KVM switch firstly. Remove the cover of the add-on slot, slide in the IP Module and make sure the module is fully inserted into the slot.

The IP Module redirects local keyboard, mouse and video data to a remote administration console. It allows you to control one or many computers locally at the server site or remotely via the Internet using a standard browser.




Figure 10. IP-Module

Figure 11.

Serial Power Control

The IP Module comes with a serial port for connecting to any serial device, such as serial PDU (Power Distribution Unit) to provide remote power control, such as power on, power off, and power cycle for the connected computers/servers.

2.4.2 CAT5 Transmitter Module

CAT5 Remote Console

Installation: Power off the KVM switch firstly. Remove the cover of the add-on slot, slide in the CAT5 transmitter module and make sure the module is fully inserted into the slot.

To extending your console up to 1000 feet away by connecting the CAT5 cable to the R-Box in the remote end.

Please refer to the “CAT5 Extender User Manual” for details.

2.4.3 CAT5 KVM Receiver (R-Box)

Please refer to the “CAT5 Extender User Manual” for details.

2.5 Power Up Sequence

Double check whether all cables/connectors are properly connected. You can check the color of keyboard and mouse connectors to ensure the connectors and cables are connected correctly.

The recommended Power Up sequence is as follows: Monitor, KVM Switch, finally the Computers.

Verify that all servers connected to the KVM Switch are powered on. If any connected servers have not been powered on, it is okay to do so at this time (servers can be powered on simultaneously). The KVM Switch emulates both a mouse and keyboard on each port and allows your server to boot normally.

When power on the KVM switch, you will see the SELECT LED of Port 1 lights up, and hear a beep sound. If you encounter an error, check your cable connections for that server and reboot. If the problem persists, please refer to the chapter “Troubleshooting” in this User Manual.

2.6 Daisy Chain Connection

Use one end of daisy chain cable to connect to the **Daisy Chain** port of Master KVM switch and connect the other end of daisy chain cable to the **Local Console** port of the next Slave KVM switch. Please repeat the connection procedures for next Slave KVM switch. You can daisy chain up to eight banks in maximum.

Note: The Daisy Chain cable is 15 lines fully connected. This is a special VGA cable, normal VGA cable have unconnected lines.




Figure 12. Daisy Chain Connection

The console OSD menu will show only the port information of the master KVM switch. When the master unit starts up, it will query all daisy chained Slave units, and automatically set up the Bank ID for each Slave unit. So the 7-seg LED on the Master unit will display 1, Slave 1 will display 2, Slave 2 will display 3, and so on. If not so, please **reset** the Master unit to update the Bank ID immediately. Hot Plug function is supported in daisy chain connection.

You can also daisy chain through computer port. This daisy chain can work with other brand of KVM switch, but you need to change the Hotkey of slave KVM switches so that the master and

slave KVM switches do not use the same Hotkey.




Figure 13. Daisy Chain through Computer Port

3. Usage

Now that you have connected your console and servers to your KVM Switch, it is ready for use.

You can control the KVM switch by three methods:

1. Using push buttons located on the front panel of the KVM Switch
2. Through the OSD (On-Screen Display)
3. Using hot-key commands through the console keyboard

It takes approximately 1-2 seconds for the video signal to refresh after switching servers. Re-synchronization of the mouse and keyboard signals also occurs. This is normal operation and ensures that proper synchronization is established between the console and the connected servers.

When you power on KVM switch, if the security function is enabled (default is disabled), it will prompt a Login window waiting for user name and password. You need to pass the authentication so can control the KVM switch.

3.1 Hotkey Commands and OSD Operations

Please refer to “Hotkey and OSD User Manual” for details.

3.2 DDC function

The KVM Switch support DDC (Display Data Channel). DDC is a VESA standard for communication between a monitor and a video adapter. Using DDC, a monitor can inform the video card about its properties, such as maximum resolution and color depth. The video card can then use this information to ensure that the computer is presented with valid options for configuring the display.

Note: The DDC function of KVM Switch will dynamically detect and copy the DDC data from the monitor that attached to the **LOCAL console port**, and that data will feed to the host computer during computer startup.

3.3 Hot Plug

The KVM Switch supports “Hot Plug” function for USB keyboard and mouse connectors.


Note:

- Normally, PS/2 port is **not** Hot pluggable.
- Normally, USB port is Hot pluggable, but some OS (Operation Systems), like Sun Micro and some Unix and Linux, do not support USB Hot Plug function. If you apply Hot Plug to this kind of OS, it will cause unpredictable behavior or shut down the Computer. Before attempting to use Hot Plug, please make sure OS and mouse software driver support the Hot Plug function.


3.4 Firmware Upgrade

Please follow the following procedures:

1. Power off the KVM switch.
2. Prepare the DC2.5M/DB9F cable, plug the DC2.5 end to the KVM switch's phone jack (marked Flash) and the DB9F end to PC serial DB9 port.
3. Power on the KVM unit. The KVM unit now will be in Flash mode, waiting for firmware download.
4. Run "**Firmware Upgrade Utility.exe**"



5. Click **Browse** to select the FW upgrade file. Please make sure you select the **correct FW upgrade file**.
6. Click **Write Flash** to start to upgrade. The upgrade process takes about 6 seconds, then display **WRITE OK** if complete the upgrade successfully.



7. Disconnect the DC2.5M/DB9F cable from the KVM unit and PC. Now the KVM unit should be running on the new firmware. The FW version can be seen on the bottom-right corner of the PORT NAME OSD window.

4. Technical Specifications

Feature	Specification
KVM Type	Combo VGA
Host Port Connector	VGA
Host Ports	8/16
Console Type	USB or PS/2
Max. Distance (KVM switch -- Host)	16 feet (5m)
Video Resolution (Local Console)	1920 x 1440
Video Resolution (Remote Console)	1680 x 1050 for CAT5-Based 500 feet remote console (ET101-C01), 1280 x 1024 for CAT5-Based 1000 feet remote console (ET101-C04), 1600 x 1200 for IP-Based remote console
Console Ports	1 Local console, plus 1 Optional Modules: CAT5-Based or IP-Based Remote Console
Flash Port	DC2.5F
CAT5-Based Remote Module	<ul style="list-style-type: none"> ■ RJ-45 Connector ■ CAT5 console up to 1000 feet away from KVM switch with superior auto-adjust RGB signals capability
IP-Based Remote Module	<ul style="list-style-type: none"> ■ RJ-45 8P8C for 10/100M Ethernet ■ DB-9 male for Configuration console, Modem, Null modem, and serial power control ■ Mini USB 2.0 receptacle
Daisy Chain	<ul style="list-style-type: none"> ■ Support Daisy Chaining with both Bus (8-layer) and Tree (2-layer) topologies ■ Connector DB15 (Female Type)
Computers Selection	On Screen Display (OSD) Menu, Hot Key, Push Button
Hotkey	Provide various Hotkey (Scroll-Lock/ Caps-Lock/ Num-Lock/ Alt/ Ctrl/ Win)
Computer Port LED's	2 LED's per Host port: ON LINE (Red), SELECT (Green)
7-seg LED	1 set for Bank display
Security	Provide ACL (Access Control List) security function, store up to 8 independent ACL's of controllable computer lists
Multilingual OSD (On Screen Display) control	8 languages (English, France, German, Spanish, Italian, Russian, Japanese, Simplified Chinese)
Auto-Scan Intervals	5 ~ 99 Sec.
Keyboard Emulation	PS/2 or USB
Mouse Emulation	PS/2 or USB
Max. Connected Computers	Up to 8192
Housing	Metal
Power	DC Power adapter : 12V, 1A
Operation Temperature	0 ~ 50°C

Storage Temperature	-20 ~ 60°C
Humidity	0~80%, Non-Condensing
Mechanical	19" Rackmount, 1U
Dimension (mm)	444.5 * 160 * 44.3

5. Cable Connectors

5.1 3-in-1 VGA Cable

HDDB15 male to one HDDB15 male plus two mini din 6-pin PS/2 connectors.



Figure 14. 3-in-1 VGA Cable Connectors

5.2 PS/2 keyboard to USB Changer

PS/2 (keyboard) to USB (keyboard and mouse) changer.




Figure 15. PS/2 keyboard to USB Changer

5.3 Daisy Chain Cable

VGA Cable: HDDB15 Male to Male




Figure 16. Daisy Chain Cable

Note:

Daisy chain needs the cable 15 lines fully connected. This is a special VGA cable, normal VGA cable have unconnected lines. Please contract your dealer for Daisy chain cable.

5.4 CAT5/5E/6 Straight Through UTP/STP Cable




Figure 17. CAT5/5E/6 Straight Through Cable Connector (8P8C)

5.5 DC2.5M to DB9F Cable

This cable is used for Flash firmware upgrade.



Figure 18. DC2.5M to DB9F Cable

6. Troubleshooting

1. No LED display on KVM Switch
 - Make sure the power adapter plugged into the KVM Switch. If the LED's still won't light, perform soft reset to KVM switch.
 - Power cycle KVM switch.
2. The computer has started up, but keyboard or mouse won't work
 - Make sure your keyboard and mouse work fine if directly plugged into the computer.
 - PS/2 computer --- keyboard and mouse are not hot pluggable, please make sure PS/2 cable are well connected then reboot the computer.
 - USB computer ---- please unplug and plug in the USB connector, wait few seconds for USB bus emulations and start up process to complete.
 - Do not press any keys on the keyboard while the selected computer is booting up. Otherwise it might cause the keyboard error or keyboard is not detected at Host side.
 - Try a different keyboard, but use only 101/102/104-key keyboard.
 - Power cycle R-Box or KVM switch.
 - Avoid moving the mouse or pressing the mouse buttons when switching ports.
3. No video signal is displayed on the monitor.
 - Connect your monitor directly to the server to verify that your monitor is functioning properly.
 - Please check if all connectors are connected properly
 - The power adapter is not connected to the R-Box or KVM switch.
 - Use hotkey "SPACE" to bring up the OSD, and confirm the port is selected and connected to a server
 - See next item, make sure the computer VGA output resolution match with the monitor's resolution
4. The computer VGA resolution does not match the monitor's resolution
 - Make sure VGA resolution works fine if directly connect the monitor to the computer.
 - Please turn off the computer, wait few seconds then turn on again. Notice that during computer startup, it will try to obtain the information of the connected monitor resolution from its VGA port. So before computer startup, the monitor and KVM switch should be already ON and running.
 - The DDC function of KVM Switch will dynamically detect and copy the DDC data from the monitor that attached to the **LOCAL console port**, and that data will feed to the host computer during computer startup.
 - Please notice the R-Box support DDC function, but it does not support monitor hot plug. Hot plug the monitor may cause this problem.
 - When you want to change the monitor, please power off the R-Box and wait for 10 seconds, then connect the new monitor to the R-Box. Power on the monitor, finally power on the

R-Box, so R-Box can detect the monitor settings and pass the settings to the computer.

- The recommended Power ON sequence is as follows: monitor, KVM Switch, finally the computers.

5. Video signal is foggy or unclear on the screen

- Please check if the VGA connector connected firmly.
- There are various of CAT5 cables, such as CAT5/CAT5e/CAT6 and STP/UTP types; If your application need long distance and maintain high VGA resolution, please select high quality cables.
- For R-Box connecting to T-Module, please use R-Box Hotkey “A” to force auto-adjusting the video signal of the remote port to optimum.

7. Glossary

The following definitions are used throughout this User Manual.

- **Auto-Scan:** A mode of operation where the KVM switch scans from one port to another, on an ongoing basis, as configured by the user.
- **BANK:** The address of a daisy-chained KVM switch.
- **Console:** The all-in-one term for the keyboard, video monitor, and mouse connected to a KVM switch.
- **Console Port:** An interface receptor on the KVM switch for the console to connect to the KVM switch via cables.
- **Control:** When discussing switching between ports, control means that the console is capable of sending input to the server. Control requires that the console also has focus on the port, and is viewing it.
- **DDC:** Short for Display Data Channel, a VESA standard for communication between a monitor and a video adapter. Using DDC, a monitor can inform a computer's video card about its properties, such as maximum resolution and color depth, to ensure that the user is presented with valid options for configuring the display.
- **Daisy-Chain:** A configuration of multiple KVM switches that are connected one to another in a series. A KVM switch daisy-chain uses common settings to allow seamless, complex interactions between multiple consoles for control over many servers.
- **HID:** Human Interface Device, the USB device class that includes keyboards and mice.
- **Host/Computer Port:** An interface receptor on the KVM switch for the computer/server to connect to the KVM switch via cable.
- **KVM:** Literally "Keyboard Video Mouse", this term refers to technology that allows two or more computers to be controlled by one keyboard, video monitor, and mouse; some switches that use KVM technology enable sharing of other peripherals such as audio speakers, microphones, and printers.
- **KVM Switch:** A device that allows a user to access and control multiple servers from a single console. It has at least one console port and multiple server ports.
- **OSD:** On-Screen Display, a Graphical User Interface that can be used to control and configure the KVM switch.

8. Certifications

FCC

This equipment has been tested and found to comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received. Include interference that may cause undesired operation.

CE

This equipment is in compliance with the requirements of the following regulations: EN 55 022: CLASS B.

RoHS

All contents of this package, including products, packing materials and documentation comply with RoHS.

